



ERICSSON

# TIMING IN PACKET NETWORKS

STEFANO RUFFINI – 9 MARCH 2015

# CONTENTS



- › Background
- › Frequency sync via packets
- › Two-Way Time Transfer
- › NTP/PTP Details
- › Impairments, Packet-based Metrics for frequency and time

– Note: Special thanks to Christian Farrow (Chronos) and Kishan Shenoi (Qulsar)




# HISTORICAL BACKGROUND



- › Packet Switching network does not require sync itself
- › CBR (Constant Bit Rate) services carried over ATM one of the first examples when sync aspects discussed in relationship with packet technologies
  - Definition of methodologies to recover the CBR sync rate have been defined to allow the transport of these services over ATM (eg. 2 Mbit/s):
    - › Network Synchronous
    - › Adaptive
    - › Differential
- › The migration of the transport network to packet networks (in particular IP), led to a generalization of these methods,
  - Need to support timing requirements of the connected networks (e.g. Mobile applications)
  - Circuit Emulation detailed performance analysis
  - Frequency sync distribution via dedicated protocols (NTP, PTP)
  - Standardized performance objectives over reference networks (ITU-T Recc. G.8261)
- › Recent increase interest to also deliver time/phase sync reference
  - Packet-based technologies required


# CIRCUIT EMULATION SYNC SOLUTIONS: PRC AVAILABLE AT THE EDGES OF THE PACKET NETWORK




Network Synchronous

From ITU-T Recc. G.8261

## Differential




# CIRCUIT EMULATION: ADAPTIVE METHODS



From ITU-T Recc. G.8261

- › No PRC traceable reference available at the edge of the packet network !
  - › Frequency sync recovered based on arrival time of the packets ...


# PACKET-BASED METHODS



From ITU-T Recc. G.8261

- › Timing information carried by *dedicated* timing packets:
  - Network Time Protocol (NTP)
  - Precision Time Protocol (PTP)


# ADAPTIVE CLOCK OPERATION



# FROM CLOCKS TO “PACKET CLOCKS”




- › “Packet clocks” can be described in a similar way ...
- › CES Packets do have a regular rhythm
- › Extension to using dedicated protocols: NTP, PTP
  - NTP/PTP Packets may not arrive regularly, but timestamps within the packets themselves mean time information can be extracted
  - Timing information contained in the arrival/departure time of the packets
  - Timestamps carried by the packets can be used to support this operation
  - Two-way or one-way protocols
  - Timing recovery process based on filtering the PDV
- › Time and frequency can be distributed from point A to point B





# PACKET-BASED EQUIPMENT CLOCK



G.8263-Y.1363(12)\_FA.1


## › Concept of «Packet Selection»:

- Pre-processing of packets before use in a traditional clock to handle PDV

# TWO-WAYS TIME TRANSFER



- › Delivery of Time synchronization requires also the knowledge of «transit delay» from A to B




- › Two-ways transfer protocols (round trip delay)
  - Assumption for symmetric channel

# HOW NTP WORKS




- › T1 Originate Timestamp
  - Time request sent by client
- › T2 Receive Timestamp
  - Time request received by server
- › T3 Transmit Timestamp
  - Time reply sent by server
- › T4 Destination Timestamp
  - Time reply received by client
- › Round Trip Delay= $(T4-T1)-(T3-T2)$ 
  - Round Trip Delay = $25-10=15$
- › Clock Offset= $[(T2-T1)-(T4-T3)]/2$ 
  - Clock Offset = $[5-10]/2= -2.5$   
(Clients actual time when reply received was therefore **09:00:0225**)
- › Key Assumptions:
  - **One way delay is half Round Trip (symmetry!)**
  - Drift of client and server clocks are small and close to same value
  - Time is traceable




# NTP NETWORK ARCHITECTURE



GPS











Stratum 1



Stratum 2




Stratum 3



# IEEE 1588-2008 PTPV2 OVERVIEW





- › The Grandmaster “reference clock” sends a series of time-stamped messages to slaves.
- › Slaves process the round-trip delay & synchronize to the Grandmaster.
- › Frequency can be recovered from an accurate time of day reference (but L1 can also be used ... )
- › Best Master Clock Algorithm to define the hierarchy
- › Accuracy is possible by means of:
  - Proper packet rate (up to 128 per second)
  - Hardware time-stamping (eliminate software processing delays)
  - Timing support in the network




**Packet Slave clocks can be either stand-alone or embedded in network equipment**

# TIMING SUPPORT



# PTP TIME TRANSFER TECHNIQUE



Round Trip Delay  
 $RTD = (t2 - t1) + (t4 - t3)$

Offset:  
 (slave clock error and one-way path delay)  
 $Offset_{SYNC} = t2 - t1$   
 $Offset_{DELAY\_REQ} = t4 - t3$

We assume path symmetry, therefore  
 $One-Way\ Path\ Delay = RTD \div 2$

Slave Clock Error =  $(t2 - t1) - (RTD \div 2)$

Notes:

1. One-way delay cannot be calculated exactly, but there is a bounded error.
2. The protocol transfers TAI (Atomic Time). UTC time is TAI + leap second offset from the *announce* message.

The process is repeated up to 128 times per second.  
 (Announce rate is lower than Sync rate)



# “THE TELECOM PROFILE” (G.8265.N/G.8275.N)

- › A profile is a subset of required options, prohibited options, and the ranges and defaults of configurable attributes
  - e.g. for Telecom: Update rate, unicast/multicast, etc.
- › PTP profiles are created to allow organizations to specify selections of attribute values and optional features of PTP that, when using the same transport protocol, inter-works and achieve a performance that meets the requirements of a particular application
- › *Other (non-Telecom) profiles:*
  - IEEE C37 238 Power Distribution Industry
  - 802.11AS AV bridging (AV over domestic LAN)



# IMPAIRMENTS IN PACKET NETWORKS




- › Typical Impairments in the packet networks
  - Packet delay variations [PDV], depending on
    - › Network dimension
    - › Traffic load
    - › QoS
  - Path dependent aspects
    - › Physical path asymmetry (*particularly relevant for time synchronization*)
    - › Path rerouting
  - Interactions between the packet streams



# PACKET DELAY VARIATION (PDV)


- › Queuing
- › Equipment Configuration
- › Priority/ QoS



# PACKET DELAY VARIATION (PDV), CONT.



## › Head of line blocking



- A packet arrives in the HPQ, just when a packet from the LPQ has begun transmission
- The packet from HPQ is blocked till the LPQ packet is transmitted
- With more complex prioritization scheme the delay due to head of line blocking could vary significantly


$$(\Delta_{PP})_{\max} \geq \left( \frac{M}{G} \right) \mu\text{s}$$

Ex. : at 100 Mbit/s, 1000 byte packet =  $8 \times 1000 / 100 \times 10^6 = 80\mu\text{s}$

# PACKET DELAY VARIATION (PDV), CONT.



Equipment implementation specifics  
e.g. the Delay variation through a single piece of equipment, with packet  
sizes



# PATH DEPENDENT IMPAIRMENTS



## › Asymmetry

- Static difference in paths between the forward and reverse paths. E.g difference in lengths of fiber
- Forward and reverse paths pass through different node

## › Rerouting

- Leads change in path delays and can “confuse” the algorithms.

# KEY ASPECTS OF PERFORMANCE





- › Packet Delay Variation (PDV) is a major contributor to “clock noise”
  - Related to number of hops, congestion, line-bit-rate, queuing priority, etc. Time-stamp-error can be viewed as part of PDV
- › Clock recovery involves low-pass-filter action on PDV
  - Oscillator characteristics determine degree of filtering capability (i.e. tolerance to PDV)
    - › Higher performance oscillators allow for longer time-constants (narrower bandwidth == stronger filtering)
    - › Lower performance (less expensive) oscillators may be used (may require algorithmic performance improvements)
- › Performance improvements can be achieved by
  - Higher packet rate
  - Controlling PDV in network (e.g. network engineering, QoS)
  - Timing support from network (e.g. *boundary clocks* in PTP)
  - Packet selection and/or nonlinear processing

# NOTION OF “BEST PACKETS”




- › The impact of PDV can be mitigated by means of a suitable classification and selection of packets
- › The “minimum delay” approach is presented as an example. Depending on the network characteristics other approaches may be more suitable
- › The assumption that the path is constant over the interval of observation implies a PDV with a distribution function with a slowly changing floor (i.e. minimum delay that a packet can experience)
- › In many cases it has been observed that a reasonable fraction (e.g. x%) of the total number of packets will traverse the network at or near this floor
- › Using only these packets in the timing recovery mechanism would allow to significantly reduce the impact of the PDV on the quality of the recovered reference timing signal



# SYNC METRICS IN PACKET NETWORKS






- › The Network Element clock output metrics (computed from TIE measurements) can be the same (MTIE/MRTIE/TDEV)
  - Clock output requirements are determined by existing (or modified) masks
  - Some distinctions are required in case of packet clock integrated in the Base Station (no standardized output MTIE/TDEV by 3GPP)
- › Specific Metrics have been defined to better characterize the behavior of packet networks (PDV) delivering the timing reference
  - E.g. metrics that associate PDV with Frequency Offset or phase variation
  - Tolerance masks/Network limits are used by network operators and clock manufacturers
  - Packet selection methods can be justified








# PEAK-TO-PEAK JITTER NOT SUFFICIENT



phase

pdf

TDEV and minTDEV




Peak-to-peak jitter = 11.5ms

Peak-to-peak jitter = 10ms

# FLOOR PACKET PERCENTAGE



Family of metrics based on counting amount of packets, observed for any window interval of  $t$  seconds within a fixed cluster range starting at the observed floor delay and having a size  $\delta$




*Floor Packet Percent (FPP)* defined in terms of percentage of packets meeting these criteria

# TIME SYNCHRONIZATION VIA PTP: ASYMMETRY RELATED IMPAIRMENTS

- › The basic principle is to distribute Time sync reference by means of two-way time stamps exchange

Time Offset =  $t_2 - t_1 - \text{Mean path delay}$

Mean path delay =  $((t_2 - t_1) + (t_4 - t_3)) / 2$



- › As for NTP, also in case of PTP Symmetric paths are required:
  - Basic assumption:  $t_2 - t_1 = t_4 - t_3$
  - Any asymmetry will contribute with half of that to the error in the time offset calculation (e.g. 3  $\mu\text{s}$  asymmetry would exceed the target requirement of 1.5  $\mu\text{s}$ )

# ASYMMETRY DUE TO THE TRANSPORT TECHNOLOGIES




- › Different paths in Packet networks
  - Traffic Engineering rules in order to define always the same path for the forward and reverse directions
- › Different Fiber Lengths in the forward and reverse direction
  - Additional problem: DCF (Dispersion Compensated Fiber)
- › Different Wavelengths used on the forward and reverse direction
- › Asymmetries added by specific access and transport technologies
  - GPON
  - VDSL2
  - Microwave
  - OTN

# COMBINED PTP-SYNCE



- SyncE as “frequency assistance” to 1588



- Gives immediate “frequency lock” to 1588 client
- SyncE & 1588 functionality may be in the same node/element
- SyncE might be used for “Time sync holdover”

# REFERENCES



- › Packet Timing in ITU-T: ITU-T G.826x series, G.827x series,
- › ITU-T general definitions: G.810, G.8260
- › NTP: IETF RFC 5905/6/7/8
- › PTP: IEEE 1588-2008
- › CES: RFC 5087, RFC 5086, RFC4533, ITU-T Y.1413, ITU-T Y.1453, MEF3, MEF 8



**ERICSSON**